

## Configuration

Jumper1 (JP1) is used to set **30/60** second pulse interval.

Jumper3 (JP3) is used to set 0.5 second pulse interval

Jumper4 (JP4) is used to set 1 second pulse interval

Push Button 1 (Green) is used to set the '**Advance**' mode

Push Button 2 (Red) is used to set the '**Hold**' mode.

